

Thank you for purchasing a Sealey Product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.


1. SAFETY INSTRUCTIONS

- WARNING!** Ensure Health & Safety, local authority and general workshop practice regulations are adhered to when using this equipment.
- ✓ Familiarise yourself with the application and the limitations of the stripper, as well as the potential hazards.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- ✓ Keep the stripper clean for best and safest performance.
- ✓ Check moving parts alignment on a regular basis.
- x **DO NOT** use the stripper for any purpose other than that it was designed for.
- x **DO NOT** operate the stripper if any parts are damaged or missing, as this may cause failure and/or personal injury.
- ✓ When not in use store in a safe, dry, childproof location.
- WARNING!** Always wear appropriate hand and eye protection when operating the stripper.

2. INTRODUCTION & SPECIFICATION

Model No:AK3810

Stripping Capacity:0.8, 1, 1.3, 1.6, 2, 2.6mm, 20, 18, 16, 14, 12, 10, AWG



3. OPERATION

- 3.1 Slide Safety Lock fully up to lock the tool closed (Fig.3). Slide the Safety Lock to the half way position (Fig.4) to allow the tool to open half way. Slide the Safety Lock to the bottom position (Fig.5) to allow the tool to open fully and to be reverse switched from wire stripper to wire cutter.



Environmental Protection.

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycle centre and disposed of in a manner which is compatible with the environment.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

SEALEY Professional
TOOLS
Auto Service Line

Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR

 01284 757500

 www.sealey.co.uk

 01284 703534

 sales@sealey.co.uk