



INSTRUCTIONS FOR
AIR CAULKING GUN
MODEL NO: **AK41.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Wear eye protection



Wear Gloves



Wear ear protection

1. SAFETY

- WARNING!** Disconnect the gun from the air supply before changing accessories, servicing or performing any maintenance.
- ✓ Maintain the gun in good condition. Replace or repair damaged parts. Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ Avoid unintentional operation.
- ✓ Ensure caulking compound manufacturer's instructions are carefully followed.
- ✗ **DO NOT** hold gun or attachments close to your face (especially eyes, ears, etc.) and do not point gun or air hose at other persons or animals.
- ✗ **DO NOT** carry by the air hose, or yank the hose or the gun from the air supply.
- ✗ **DO NOT** use the gun for any purpose other than that for which it is designed.
- ✗ **DO NOT** operate the gun if damaged.
- ✗ When not in use disconnect from the air supply and store in a safe, dry, childproof area.

2. INTRODUCTION

Accepts standard 330ml cartridges. Fitted with trigger control for smooth application of caulking.

3. SPECIFICATION

Model no:AK41.V2
 Cartridge: 215 x 50mm
 Air supply: 30-40psi
 Air consumption: 15cfm
 Air inlet: 1/4" BSP





fig.1

4. ASSEMBLY

- WARNING!** Disconnect the gun from the air supply before changing accessories, servicing or performing any maintenance.
- ✓ The gun is fitted with a 1/4" BSP male coupling. Use of a suitable coupling (not supplied) is required.
- ✓ To maintain the gun in good condition, replace or repair damaged parts. Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.



5. OPERATION

- ☐ **WARNING!** Ensure you read, understand and apply the safety instructions in Section 1 and follow any manufacturer's instructions on the caulking container.
 - ✓ Avoid unintentional operation.
 - ✓ Ensure caulking compound manufacturer's instructions are carefully followed.
 - ✗ **DO NOT** hold gun or attachments close to your face (especially eyes, ears, etc.) and **DO NOT** point gun or air hose at other persons or animals.
 - ✗ **DO NOT** operate the gun if damaged.
 - ✓ Keep children and unauthorised persons away from the work area.
 - ✓ When not in use disconnect from the air supply and store in a safe, dry, childproof area.
- 5.1. Screw the gun cylinder A to the gun body (fig.1).
 - 5.2. Unscrew the end cap B from the cylinder and insert the caulking cartridge. Screw on the end cap B to retain the cartridge.
 - 5.3. Ensure air supply is regulated to no more than 40psi (2.75 bar) and then attach air hose to the gun.
 - 5.4. Aim the nozzle of the cartridge into a safe area and depress the gun trigger to check for correct operation.

6. MAINTENANCE

- 6.1. Clean the gun after each use.
- 6.2. Check fittings and trigger components are sound and secure before each use.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk