



THE TOOL COMPANY

MOBILE ENGINE REPAIR WORKBENCH

OPERATOR INSTRUCTION MANUAL



Model No

AP1200MW.V3

Important: Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.

Table of Contents

1. Introduction	2
1.1 Intended Use	2
1.2 Description	2
2. Safety Symbols	3
3. Safety	3
3.1 Operators Safety	3
4. Specification	3
5. Contents	4
6. Assembly	5
7. Consumables & Accessories	7
8. Maintenance	7
9. Warranty	7
10. Aftersales Support	7
11. Parts Information - AP1200MW.V3	8

1. Introduction

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

1.1 Intended Use

The Mobile Engine Repair Workbench is intended for supporting and positioning vehicle engines during maintenance, repair and assembly work. Its mobile design allows the workbench to be easily moved around the workshop as required.

1.2 Description

Heavy-duty steel construction with a tough powder-coated finish provides long-lasting corrosion protection. The angled worktop channels fluids to a single drain point, making it ideal for engine, transmission, gearbox, and hydraulic work. Fluids are collected in a removable polyethylene container for quick and clean disposal. A height-adjustable shelf provides convenient storage for tools and parts, while the lockable drawer keeps essential items secure. Four swivel castors, including two with brakes, ensure smooth manoeuvrability and stable positioning during use.

© Jack Sealey Limited

All content in this manual, including but not limited to text, images, graphics and logos is the property of Jack Sealey Ltd. or its licensors and is protected by copyright, trademark, and other intellectual property laws. You may not reproduce, distribute, modify, or otherwise use any content without prior written consent.

Disclaimer: All errors and omissions excluded. It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See www.sealey.co.uk for the latest information.

Country of origin: China.

2. Safety Symbols



Refer to
instruction
manual

3. Safety

3.1 Operators Safety

! **WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this trolley.

- Always load evenly with the centre of gravity of the load as near centre of the trolley as possible.

⊘ **DO NOT** overload the trolley - see Specifications - section 3.

- Use the trolley in a suitable work area.
- Keep the work area clean, uncluttered and ensure there is adequate lighting.
- Keep the trolley clean and tidy in accordance with good workshop practice.

⊘ **DO NOT** use the trolley for any purpose other than that for which it is designed.

⊘ **DO NOT** stand on the trolley, use it as a ladder or allow others to ride on the trolley.

- Use the wheel locks to prevent the trolley from inadvertently moving.

⊘ **DO NOT** leave unattended, especially when loaded, unless the wheels are locked, chocked or the trolley otherwise secured.

⊘ **DO NOT** use trolley on uneven ground and **DO NOT** run over curbs or steps - use a ramp.

⊘ **DO NOT** use trolley if any part is significantly damaged, paying particular attention to the wheels.

- Keep children and unauthorised persons away from the work area.

4. Specification


Model No:	AP1200MW.V3
Nett Weight:	61.1kg
Overall Size:	1200 x 640 x 872mm
Worktable Size:	1195 x 635 x 10mm
Large Drawer (x1):	340 x 430 x 130mm
Shelf Size:	1110 x 460 x 30mm
Capacity:	250kg

5. Contents

fig.1

Item	Description	Qty
A	Swivel Castor	2
B	Swivel Castor with Brake	2
C	Vertical Upright	4
D	Top Shelf	1
E	Bottom Shelf	1
F	Oil Storage Tray	1


Item	Description	Qty
G	Drawer	1
H	M8x25mm Hex Bolt	32
I	Spring Washer	40
J	Flat Washer	40
K	Castor Nut M8	16
L	M8x65mm Hex Bolt	8




6. Assembly

6.1 Refer to contents page for assembly.


Step.1




Step.2



Step.3



Step.4



7. Consumables & Accessories

A wide range of consumables and accessories are available.

Visit www.sealey.co.uk to explore our extensive range.

8. Maintenance

- 8.1. Regular checks on the item will be required due to the nature of the service it is intended for.
- 8.2. Attention to be paid to swivel castors to ensure stable, free and smooth rolling action.
- 8.3. Frame fixings to be checked and tightened regularly to ensure rigidity of structure.

9. Warranty

- Guarantee is 12 months from purchase date, proof of which is required for any claim.



Please note that guarantee claims must be made via the place of purchase where you may need to provide proof of purchase. All consumable items are under no warranty period. All warranties exclude general wear and tear and misuse, see our terms of business for more details.

10. Aftersales Support

We are committed to supporting our products throughout their lifetime.

- If your product is outside of the warranty period, we offer an extensive range of spare parts along with expert technical advice to help keep your equipment in working order.
- Our technical team is on hand to assist 8.30am-5.00pm Mon-Fri with fault finding, repairs and general product queries.


Telephone 01284 757505

Email: technical@sealey.co.uk



If required, products can also be returned to Sealey or one of our authorised repair agents for inspection, servicing or repair at a reasonable cost.

11. Parts Information - AP1200MW.V3



Item	Part No.	Description	Qty
A	AP1200MW-V3-A	Wheel, Swivel Castor, 4 Bolt	2
B	AP1200MW-V3-B	Wheel, Swivel Castor, 4 Bolt (c/w Brake)	2
C	AP1200MW-V3-C	Leg	4
D	AP1200MW-V3-D	Top Shelf	1
E	AP1200MW-V3-E	Bottom Shelf	1
F	AP1200MW-V3-F	Oil Storage Tray	1

Item	Part No.	Description	Qty
G	AP1200MW-V3-G	Drawer	1
H	SS825.S	Hex Head Set Screw M8 X 25 Zinc	32
I	SWM8.S	Spring Washer M8 Zinc	40
J	FWM8.S	Flat Washer M8 Zinc	40
K	SN8.S	Steel Nut M8 Zinc	16
L	HHB865.S	Hex Head Bolt M8 x 65mm	8



Product Registration

It's quick and easy to register your warranty online at www.sealey.co.uk. Just log in or create a free MySealey account, then head to the 'My Products' section to fill out the short warranty registration form. If your product is advertised with a free extended warranty upon registration, this will activate your extended warranty.



Environment Protection

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



Jack Sealey (EU) Ltd t/a Sealey Group Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Jack Sealey Ltd t/a Sealey Group Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
 Tel: 01284 757500 • Email: sales@sealey.co.uk • Web: www.sealey.co.uk