



**Dellonda Outdoor Dining Table Weather Resistant, Glass Top
80x80cm Anthracite**



Model No. DG207

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

Important Information

Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.



Refer to
instruction
manual



Wear gloves
during
assembly

Specification

Model No.: DG207

Dimensions (W x D x H) 800 x 800 x 760

Supplied with fixings (12 short screws and 16 long screws)

About the Product


Outdoor/Indoor dining table. Features tempered glass table top. Stylish anthracite finish. A perfect match for Dellonda Model No. DG201 (Set of 4 Dining Chairs). Some simple assembly is required.

Safety Instructions

- **WARNING!** The warnings, cautions and instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into these products, but must be applied by the users.
- Ensure the items are assembled properly and securely.
- To avoid tipping, use on firm, level ground.
- **DO NOT** expose furniture to high temperature heat sources i.e. barbecue.
- **DO NOT** stand on furniture.

Assembly

- **CAUTION** It is inherent that edges and corners can cause cuts if improperly handled during assembly. **BE CAREFUL**, wear correct work gloves.
- Lay the table face down on a clean and dry surface.
- Locate a leg in the corner of the table.
- Using 4 long screws (2 per side member), fix the leg to the holes in the table side member (fig.1).
- Using 3 short screws, fix the leg tab to the holes in the table cross member.
- **DO NOT** over tighten screws to avoid damage to the table material.
- Stand the table upright and carefully and gently place the glass table into the frame.



Maintenance

- Regularly check all fixings are secure.
- Perform maintenance at least once a year in order to extend the life of your furniture.

Cleaning

- Regularly wipe down the unit with hot soapy water.
- Any modifications of these items may be dangerous and are not permitted. **DO NOT** alter parts supplied by the manufacturer.

Storage

- We recommend you use covers to protect these items when not in use. Covers must be removed periodically to minimise moisture build up.

Environment Protection and Waste Protection

Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of its useful life, please dispose of it in an environmentally friendly way. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. Guarantee is 12 months from purchase date, proof of which is required for any claim.

Dellonda Limited

Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

01284 757575

support@dellonda.co.uk

www.dellonda.co.uk