

8\*15.5CM

Intelligent Touch Screen inflator pump



MODEL:RLA-2404



Tips

1. The product inflatable function can not work.  
Solution: Check the setting pressure, the preset pressure value needs to be higher than the current display pressure of the product, the inflatable function can work.
- 2.The product temperature is very high, hot.  
Solution: air compressor work will be compressed air will produce a lot of heat, heat will be conducted to the product surface, the product will work for a period of time after the temperature is very high, is a normal phenomenon. When you feel the temperature is too high, you can turn off the product, let it stop and cool down, and then work again after 10-15 minutes of cooling. After 6-10 minutes of continuous work, it is better to stop the product to cool down for 15 minutes.
- 3.Digital products in connection with the tire, immediately stop working after the start, the dial shows a very high value;  
Solution: the product air tubes and tires are not connected to the compressed air congestion in the air tubes, the air pressure rises so that the air pump detects that the pressure has reached the preset value so shutdown, this time you should check the tire nozzle is installed on the nut and other limiting devices to remove the tire nozzle on the limiting device, and will be the air pump connectors Press to the end to hear the sound of air leakage.  
Air pump pressure is not allowed.
- 4.Solution; air pump factory after the standard air pressure calibration tuning, error is very small, when the air pressure value and your other test props to produce a certain gap, the actual error value is very small and does not affect the car driving, both props detection of air pressure will be a certain error with the standard air pressure, the error is not more than 0.2bar will not affect the normal use of the.  
1bar=14.5psi=100kpa  
The use of the output interface of this product is limited to
- 5,the charging of this product, please do not carry out any irregularities in charging and discharging, which causes all the consequences by the user's own responsibility.

Product parameter


Model	Car Inflatable Pump
Name	RLA-2404
Power	56W
Voltage	DC 7.4V==
Charging Voltage	DC5V=1A

Small details of product use

1. The product has an anti-touch function: when the air pump works for a long time when the air pressure is 0, the air pump automatically stops working.
- 2.The product comes with a hibernation function: when the air pump is not operated for a long time, it will automatically enter the hibernation mode. When the product is dormant, long press the inflatable control key can wake up the system.



Screen description



Operation Action	Operation Description	Remarks
Power on	Press and hol " " for 2 seconds to turn it on	
Shutdown	Press and hold the " " buttonfor 2 seconds to turn off the and 40 turn of the workina condition	
Unit switching	Press and hold down the " " key to switch the unit of "PSI, BAR, KPA, KG/CM" in the power-on state.	
Inflatable mode switching	Press and hold the " " button to switch between the five modes of "Free Mode, Bicycle, Motorcycle, Car and Basketball" under power-on condition.	
Preset pressure value switching	Click " + " or " - " key to set the target pressure value under power-on condition, or long press to set the presure value in quick succession.	
Lamp mode switching	Click " " button to turn on, white light is always on, click again red low-frequency blinking, click again red high-frequency blinking, click again of	
Start the air pump	Click the " " key in the power-on state, the air pump works	
Turn off the air pump	When the air pump is in working condition, click the " " button to stop the air pump.	

Instructions for use

1. Fasten the air nozzle on the air pump hose to the tire nozzle and make sure the nozzle is fully fastened without air leakage.
- 2.Press the switch of the air pump, the air pump will be energized and start to work. The pump works with high temperature and high pressure gas, body heating is a normal phenomenon, do not touch the inflatable hose after use, be careful to burn your hands! (Note: preset pressure type air pump please set the pressure first electronic meter with memory function, will remember the current set pressure for next time use)
- 3.When inflating, please pay attention to the pressure value of the air pump on the pressure gauge changes, when the pressure reaches the required pressure, please toggle the switch to the off state (preset pressure model pressure to reach the set pressure automatically shut down) will be the air pump nozzle from the tires to remove, the inflatable is complete. Ordinary car tire pressure is 2.3-2.5 BAR, 28-35 PSI)
- 4.The air pump comes with several air nozzles that can be used for counting life rings, balloons, inflatable toys, and other inflatable products. To inflate a car tire, simply dock the nozzle on the inflatable hose directly to the tire nozzle.

Safety precautions

1. In order to maximize the inflatable life, it is recommended to stop the machine for 15 minutes to cool down whenever you work continuously for 8-10 minutes. (It can effectively reduce the wear and tear of the piston)
- 2.When using the inflatable pump, please pay attention to the pressure change at any time, this product is an electric appliance, please do not run it unattended alone.
- 3.When using the inflatable pump, remember to keep it away from humid environment and serious sandy environment to prevent water and dust from entering the motor and causing damage to the motor.
- 4.Do not place this product in extreme environments (e.g., rain and prolonged sunlight, etc.).
- 5.Do not allow children or people with disabilities to use this product to avoid injury.
- 6.Do not immerse the product in water, otherwise it will cause damage to the internal circuit.
- 7.Do not use the product near a vapor or fireplace to avoid damage.

Setting

1. When using the inflatable pump, please hold it gently and avoid impact.
- 2.Please do not put the pump too close to fire source and other high temperature places.
- 3.3. Please do not leave the battery in too hot or too cold places (such as sealed compartments in summer or winter), it is recommended to use it in 0-35°C ambient temperature, please store it in a cool and dry place.
- 4.When the unit is not used for a long time, it is recommended to charge it once every three months.
- 5.Please do not disassemble or modify the battery, and use the battery for other purposes.
- 6.When the battery product accidentally swelling or outflow of liquid, smoke, please stop using it immediately.
- 7.Before disposing of the appliance, remove the battery pack from the appliance and open the top and bottom covers with the aid of a tool to remove the battery.
- 8.When removing the battery, the appliance must be disconnected from the power supply.
- 9.Batteries should be disposed of safely.

Before use

1. Please check whether the adapter charging cable is intact before charging;
- 2.After long-term storage, please use it after the battery is full.
- 3.Before charging, please make sure the switch is turned off, it is strictly prohibited to use it while charging.

In use

Do not use this product in explosive gas.