



4-PIN UNIVERSAL WINCH REMOTE CONTROL

MODEL NO: **UWRC01**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual

1. SAFETY

- * **DO NOT** enter the danger zone (the area of the winch drum, the fairlead (if fitted), the pulley block (if used) the hook and the motor).
 - * **DO NOT** approach or span the wire rope whilst the winch or puller is under load.
 - * **DO NOT** operate a winch or puller when under the influence of alcohol, drugs or medication.
 - ☐ **WARNING!** Turn off the power switch on the side of the hand held control unit, before working in or around the fairlead or wire rope drum (the danger zone).
 - ☐ **WARNING!** Never tuck the hand held control unit under the arm, or allow anyone else to hold it, so as to avoid it being accidentally activated.
 - ✓ Wear eye protection, insulated work clothes, non-slip shoes, keep hair tied up and wear thick leather gloves. Remove all jewellery.
 - ✓ Inspect winch or puller, wire rope, hooks and other accessories frequently. A mashed, pinched, kinked or frayed wire rope with broken strands should be replaced at once, because a damaged rope has reduced load carrying capability.
- NOTE:** The safety precautions and instructions discussed in this manual can't cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product and must be applied by the operator.

2. INTRODUCTION

Universal wireless remote control kit has a 4-pin plug-and-play receiver. With a range of up to 30m (dependant on environment), a wireless remote control is an essential accessory. Weatherproof receiver and handset making it ideal for off-roaders and recovery trucks, enabling the operator to stand well clear or sit in the cab (provided there are no restrictions).

3. SPECIFICATION

Model No:..... **UWRC01**
 Battery:..... MN21 23A (supplied)
 Contents:..... Handheld Control Unit (x1)
 4-Pin Plug-and-Play Receiver Unit (x1)
 Range: 30m

4. OPERATION

- 4.1. Fit the battery by sliding off the cover, taking care to observe the polarity indicated on the circuit board. Replace cover.
- 4.2. Remove the waterproof cover from the four pin socket on the end of the winch and fit the receiver unit. Take note of the orientation of the key way on the receiver unit. Tighten the securing ring.
- 4.3. Turn on the switch on the side of the hand held control unit.



5. BATTERY REMOVAL

- 5.1. Slide the battery cover off and remove the battery, dispose of it in accordance with local authority guidelines. Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR
PURCHASE HERE



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk