

WHEELBARROW 65LTR GALVANIZED

MODEL NO: WB65

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

SAFETY

- Always distribute the load evenly over the surface of the wheelbarrow.
- DO NOT overload the wheelbarrow.
- × DO NOT use wheelbarrow on uneven ground and DO NOT run over curbs or steps - use a ramp.
- **DO NOT** allow others to ride in the wheelbarrow.
- DO NOT use the wheelbarrow if any part is damaged, paying particular attention to the wheel.
- DO NOT inflate the tyre to more than 25psi.

2. INTRODUCTION

Lightweight galvanized steel wheelbarrow ideal for a wide range of gardening and light construction applications, as well as general domestic use. Constructed with strong tubular steel frame and rubber gripped handles. Fitted with 340mm pneumatic tyre.

3. CONTENTS

- Pan
- Frame x 2
- Frame spacer x 2
- Pan support
- Bolt x 6
- Nut x 6
- Washer x 6
- Wheel assembly
- Wheel
- Axle Bolt
- Axle Nut
- Axle Sleeve
- Large Washer x 4

4. SPECIFICATION

| Model No: | WB65 |
|------------------|------|
| Capacity: | 65L |
| Capacity weight: | |

ASSEMBLY

- 5.1. Take the wheelbarrow pan and lean it up against a wall or use an assistant to hold it upon its end.
- 5.2. Next attach the frames to the underside of the pan. Ensure the end of the frame to which the wheel will attach, kicks outward as in (fig.2).
- Place a frame spacer between the frame and pan over 5.3. the pre-drilled holes (fig.1).
- 5.4. Slide on washers and Insert the bolts through the spacer and frame and secure with nuts. Repeat for other frame.


NOTE: Only tighten finger tight at this time.


- Place the pan support between the frame and pan where the two 5.5. single drilled hole are, ensure the support is around the correct way and the kink follows the curve of the pan (fig.1).
- 5.6. Secure in place by feeding bolt through the pan, support, then frame and secure with nut.
- Slide the axle sleeve through the centre of the wheel. 5.7.
- Slide one large washer onto the axle bolt, then insert through the 5.8. frame another washer then through the wheel. Slide a washer onto the axle bolt then though the frame then the last washer and secure with the axle nut (fig.2).

Original Language Version

NOTE: Ensure there is a washer either side of the frame (fig.2).

5.9. Tighten all nuts and bolts, be careful not to over tighten.





6. OPERATION

- **6.1.** Check tyre pressure on a regular basis.
 - **DO NOT** inflate above 25psi.
 - DO NOT overload the wheelbarrow and ensure that the load is evenly distributed before setting off.
- **6.2.** Proceed at a safe speed especially at corners where there could be a danger of the load shifting.
- **6.3.** Extra care should be taken on inclined surfaces.
- **6.4.** Where there is a curb or step, a ramp should be used.

7. MAINTENANCE

- **7.1.** Periodically check all nuts and bolts are tight.
- 7.2. Keep Clean.
- **7.3.** Store upright in a dry place.
- **7.4.** Lubricate axle.
- **7.5.** Hose off and dry after use.

Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or telephone 01284 757500



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

1. 01284 757500 01284 703534 sales@sealey.co.uk www.sealey.co.uk