


Parts Information:

Space Warmer® Paraffin/Diesel Heater 125,215Btu/hr with Chimney **Model No: AB125HE.V2**



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk





Parts Information:

Space Warmer® Paraffin/Diesel Heater 125,215Btu/hr with Chimney Model No: AB125HE.V2

Item	Part No.	Description
1	SL1087007533	Fan
2	SL1040012233	Motor
3	SL1001001300	Joint
4	SL1049001500	Capacitor
5	SL20220006	Coil
6	SL1043004500	Cable and Connector
7	SL1076004300	Small Hose
8	SL1067004100	Fitting
9	SL20220010	Pump
10	SL1018002900	Washer
11	SL1066001300	Adaptor
12	SL20120049	Olive
13	SL1066001600	Fitting
14	SL20160024	Backflow Hose
15	SL20160016	Inflow Hose
16	SL20500004	Photocell (c/w Fixings)
17	SL1039037433	HT Lead
18	SL1094135533	Burner Head
19	SL20210061	Nozzle
20	SL20300010	Electrode
21	SL1001017500	Cover
22	SL20330010	Transformer
24	SL20320003	Power Switch (Rocker)
25	SL20020010	Сар
26	SL2500EURP2	Power Supply Cable
27	SL20350007	Fuse
28	SL1002002855	Сар
29	SL20320022	Reset Push Button
30	SL20070022	Сар
31	SL20430000	Socket
32	SL20430002	Socket Casing
33	SL20010060	Control Panel
34	SL20010048	Spacer
35	SL20470019	Flame Control Unit
36	SL20160020	Suction Hose

Item	Part No.	Description
37	SL1066001700	Fitting
39	SL1017002800	Nut
40	SL1094134900	Filter Bracket
41	SL1066001500	Fitting
42	SL1086002500	Oil filter
43	SL1066001300	Adaptor
45	SL1066001600	Fitting
48	SL20100002	Suction Fitting
49	SL1095011800	Handle
50	SL1090007533	Guard
51	SL05511	Air Inlet
52	SLTOMM411	Inspection Cover
53	SLMIR03711	Upper Body
54	SL20050006	Сар
55	SL1002002000	Gasket
56	SL1002002100	Rubber Ring
57	SL1086001000	Filling Filter
58	SL1005000900	Сар
59	SL1094046500	Tank Support
60	SL1023001500	Spring
61	SL1005002000	Wheel Cap
62	SL20230219	Circlip
63	SL1004001300	Wheel
64	SL1094134100	Axle
65	SL1094135733	Air Lock
66	SL1095011233	Chamber Inlet
67	SLMIR037	Combustion Chamber
68	SLMIR5H	Chamber Shield
69	SL055A11	Air Outlet
70	SL20620679	Flue Collar
71	SL1017002200	Fixing Clip
72	SLMIR03711A	Lower Body
	SL1041001700	Power Supply Lamp (Not Shown)
	SLM020	Tank (Not Shown)
	SL1036004400	Thermal Cutout (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

01284 757500



01284 703534



sales@sealey.co.uk

