



Item	Part No.	Description
1	BSL103.01	Main Body
2	BSL103.02	Piston
3	BSL103.03	Top Cover
4	BSL103.04	Arms
5	BSL103.05	U-Seal
6	BSL103.06	Dowel Pins
7	BSL103.07	Conical Spring
8	BSL103.08	Bolt
9	BSL103.09	Air Release Button
10	BSL103.10	Insert

Item	Part No.	Description
11	BSL103.11	Spring
12	BSL103.12	O-Ring, (Ex: 8.24 In: 5.61 Cs: 1.32)
13	BSL103.13	Air Control
14	BSL103.14	Slotted Insert
15	BSL103.15	Button
16	BSL103.16	Nut
17	BSL103.17	Rubber Handle
18	BSL103.18	Air Adaptor
19	BSL103.19	Nameplate
--	BSL103.20	Air Release (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.