



Item	Part No.	Description
1	CD2013TTV2.01	Timer Cover
2	CD2013TTV2.02	Timer
3	CD2013TTV2.03	Front Panel
4	CD2013TTV2.04	Motor
5	CD2013TTV2.05	Motor Cover
6	CD2013TTV2.06	Heat Insulating Felt
7	CD2013TTV2.07	Top Frame
8	CD2013TTV2.08	Heating Bracket
9	CD2013TTV2.09	Back Panel
10	CD2013TTV2.10	Heating Element
11	CD2013TTV2.11	Handle Support
12	CD2013TTV2.12	Handle

Item	Part No.	Description
13	CD2013TTV2.13	Foot
14	CD2013TTV2.14	Lower Support
15	CD2013TTV2.15	Thermostat
16	CD2013TTV2.16	Fan
17	CD2013TTV2.17	Temperature Control Knob
18	CD2013TTV2.18	Fan Cover
19	CD2013TTV2.19	Switch, Rocker (Double, Black) Illuminated - 16A / 250V
20	CD2013TTV2.20	Switch, Rocker (Black) Illuminated - 16A/250V-- T125/55
21	CD2013TTV2.21	Temperature Control Support
22	CD2013TTV2.22	Power Cord Grip

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.