



Item	Part No.	Description
1	CP1201.01	CHUCK SCREW (L.H)
2	CP1201.02	KEYLESS CHUCK 1/2"
3	CP1201.03	GEAR CASE
4	CP1201.04	MOTOR GEAR
5	CP1201.05	MOTOR
6	CP1201.06	SPEED SELECTOR SLIDE BUTTON
7	CP1201.07	SPEED SELECTOR SPRING
8	CP1201.08	CASING ASS'Y
9	CP1204.08	LED COVER
10	CP1204.07	BELT CLIP

Item	Part No.	Description
11	CP1204.09	FORWARD/REVERSE ROD
12	CP1201.12	SWITCH ASSEMBLY
13	CP1203.11	BATTERY CONNECTOR ASS'Y
14	CP1201.14	SPRING PLATE
15	CP1201.15	CASING SCREW
16	CP1204.12	BATTERY CONNECTION CLIP
17	CP1200BP	C/LESS POWER TOOL BATTERY 12V
--	CP1200MC	LI-ION BATTERY CHARGER 12V 1 HOUR (NOT SHOWN)
--	CP1200CB	CANVAS BAG for CP1200 SERIES (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.