



Item	Part No.	Description
1	DH11404	Indicator Light (Red)
2	DH11405	Indicator Light (Green)
3	DH11406	Control Knob
4	DH11407	Control Panel Glass

Item	Part No.	Description
6	DH11408	Door Handle
11	DH10316	PCB Board
17	DH10308	Top Heat Element
33	DH10312	Oven Light

Item	Part No.	Description
39	DH10313	Bottom Heat Element
49	DH10506	Oven Rack
50	DH11409	Oven Tray

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Jack Sealey Ltd t/a Baridi, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK

Jack Sealey (EU) Ltd t/a Baridi, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland

Tel: 01284 757575 • Email: sales@baridi.co.uk • Web: www.baridi.co.uk