



Item	Part No.	Description
1	GSA28.01	Housing
2	GSA53.02	Air Inlet
3	GSA53.03	Rubber Grip
4	GSA53.04	Trigger
5	GSA53.05	Trigger Pin
6	GSA53.06	O-Ring
7	GSA53.07	Valve Stem
8	GSA53.08	Valve Spring
9	GSA53.09	O-Ring
10	GSA53.10	Valve Plug
11	B/608ZZ	Bearing
12	GSA53.12	End Plate
13	GSA53.13	Rotor
14	GSA53.14	Rotor Blade
15	GSA53.15	Cylinder
16	SA53.V3-14	Spring Pin
17	GSA53.17	Front Plate
19	GSA53.19	Ring (Tab)

Item	Part No.	Description
20	B/6001ZZ	Bearing
21	GSA53.21	Pin
22	GSA53.22	Gear
23	GSA53.23	Gear Plate
24	GSA53.24	Thread Ring Gear
25	B/6201ZZ	Bearing
26	GSA53.26	Muffler Cover
27	GSA53.27	Clamp Nut
28	GSA53.28	Chuck Spacer
29	GSA53.29	Eccentric Nut
30	B/R8ZZ	Bearing
31	GSA53.31	Cutter Housing
32	GSA53.32	Lock Screw (Set Of 3)
33	GSA53.33	Lock Nut
34	GSA53.34	Outer Blade, Left
35	GSA53.35	Centre Blade
36	GSA53.36	Spacer (Set Of 2)
37	GSA53.37	Outer Blade, Right

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.