



Item	Part No.	Description
1	HVLP2000V2.01	Screw
2	HVLP2000V2.02	Housing, Lower
3	HVLP2000V2.03	Screw
4	HVLP2000V2.04	Cable Clamp
5	HVLP2000V2.05	Cable Sleeve
6	HVLP2000V2.06	Cable
7	HVLP2000V2.07	Housing, Upper
8	HVLP2000V2.08	Handle
9	HVLP2000V2.09	Switch, Power
10	HVLP2000V2.10	Filter
11	HVLP2000V2.11	Motor
12	HVLP2000V2.12	End Cap
13	HVLP2000V2.13	Container
14	HVLP2000V2.14	Fluid Tube
15	HVLP2000V2.15	Container Gasket
16	HVLP2000V2.16	Knob, Adjustable Nozzle
17	HVLP2000V2.17	Lock Ring
18	HVLP2000V2.18	Air Cap
19	HVLP2000V2.19	Fluid Tip

Item	Part No.	Description
20	HVLP2000V2.20	Needle, Fluid
21	HVLP2000V2.21	O-Ring
22	HVLP2000V2.22	Baffle Ring
23	HVLP2000V2.23	Spring, Trigger
24	HVLP2000V2.24	Rd Head S/T Screw M3.4 x 15mm Black
25	HVLP2000V2.25	Housing Assembly
26	HVLP2000V2.26	Hook
27	HVLP2000V2.27	Gun Body
28	HVLP2000V2.28	Fixed Ring
29	HVLP2000V2.29	Insert Plate, Rear
30	HVLP2000V2.30	Rear Adjustable Knob
31	HVLP2000V2.31	Housing, Right
32	HVLP2000V2.32	Handle Grip
33	HVLP2000V2.33	Trigger
34	HVLP2000V2.34	Trigger Pin
35	HVLP2000V2.35	Label
--	HVLP2000V2.36	Air Hose (Not Shown)
--	HVLP2000V2.37	Viscosity Cup (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.