



Item	Part No.	Description	Qty
1	IR20-V7-01	Safety Guard	1
2	IR20-V7-02	Protection Ring (for Safety Guard)	1
3	IR20-V7-03	Heat Plate	1
4	IR20-V7-04	Ceramic Fibre	1
5	IR20-V7-05	Heat Insulating Casing	1
6	IR20-V7-06	Outer Casing	1
7	IR20-V7-07	Top Handle	1
8	IR20-V7-08	Rear Cover for Outer Casing	1
9	IR20-V7-09	Flame Plate	1
10	IR20-V7-10	Injection Nozzle	1
11	IR37-V7-36	Burner Head	4
12	IR20-V7-12	Air Outlet Disc	1
13	IR37-V7-37	Fan Blade	1
14	IR37-V7-10	Ignition Needle	1
15	IR20-V7-15	Tip-Over Switch	1
16	IR37-V7-38	Support Bracket	1
17	IR37-V7-15	Sensor	1
18	IR37-V7-17	Power PCB	1
19	IR37-V7-20	Rocker Switch	1
20	IR37-V7-21	Display Window	2
21	IR20-V7-21	Rotary Knob	1

Item	Part No.	Description	Qty
22	IR37-V7-19	Rear Cover	1
23	IR37-V7-18	Display Board	1
24	IR37-V7-16	Blower Motor Assembly	1
25	IR20-V7-25	Support Plate	1
26	IR37-V7-12	Flame Cover	1
27	IR37-V7-35	Ignition Transformer	1
28	IR20-V7-28	Rear Support Plate for Fuel Tank	1
29	IR37-V7-06	Electromagnetic Pump	1
30	IR37-V7-39	Oil Outlet Plug	1
31	IR20-V7-31	Electromagnetic Pump Bracket	1
32	IR20-V7-32	Fuel Gauge	1
33	IR37-V7-25	Fuel Tank Cap (Plastic)	1
34	IR20-V7-34	Fan	1
35	IR20-V7-35	Motor Bracket	1
36	IR37-V7-33	Fuel Filter	1
37	IR20-V7-37	Fuel Tank Assembly	1
38	IR20-V7-38	Support Frame	1
39	IR20-V7-39	Reflector Plate	1
40	IR37-V7-05	Heat Insulating Wool	1
41	IR37-V7-11	Ceramic Fibre Gasket	2

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.