



Parts Issue 2  
 Issue Date 140305

ITEM	DESCRIPTION	PART No.	ITEM	DESCRIPTION	PART No.
1A	PAD NUT	MS900PS.01A	27	SCREW ST4X75C	MS900PS.27
1	SPINDLE	MS900PS.01	28	STATOR	MS900PS.28
2	SPINDLE KEY 4X5X13	MS900PS.0	29	INDUCTANCE	MS900PS.29
3	SCREW M5X16	MS900PS.0	30	CONNECTION SPRING	MS900PS.30
4	SPRING WASHER M5	MS900PS.0	31	HOUSING	MS900PS.31
5	GEAR HOUSING COVER	MS900PS.0	32	TYPE PLATE	MS900PS.32
6	BEARING 6002-2RS	MS900PS.0	33	BACK HANDLE (RIGHT)	MS900PS.33
7	BEARING COVER	MS900PS.0	34	SWITCH	MS900PS.34
8	SPRING WASHER	MS900PS.0	35	CORD CLIP	MS900PS.35
9	SCREW M4X10	MS900PS.0	36	SCREW ST4X75C	MS900PS.36
10	BIG GEAR	MS900PS.10	37	CAPACITOR 0.33µF	MS900PS.37
11	CIRCLIP FOR SHAFT	MS900PS.11	38	SWITCH BUTTON	MS900PS.38
12	BRONZE BUSHING	MS900PS.12	39	CORD/PLUG	MS900PS.39
13	REDUCER	MS900PS.13	40	RUBBER SLEEVE	MS900PS.40
14	SCREW ST5X45C	MS900PS.14	41	SCREW ST4-14F	MS900PS.41
15	E-RING	MS900PS.15	42	BACK HANDLE (LEFT)	MS900PS.42
16	BRAKE SPRING	MS900PS.16	43	SCREW ST4X18F	MS900PS.43
17	BRAKE PIN	MS900PS.17	44	SCREW ST4X22F	MS900PS.44
18	RUBBER PLUNGE	MS900PS.18	45	BRUSH CAP	MS900PS.45
19	SIDE HANDLE	MS900PS.19	46	CARBON BRUSH	MS900PS.46
20	CIRCLIP FOR SHAFT	MS900PS.20	47	BRUSH HOLDER	MS900PS.47
21	BEARING 6201-2RS	MS900PS.21	48	TIMING SWITCH	MS900PS.48
22	BEARING COVER	MS900PS.22	49	NAME PLATE 1	MS900PS.49
23	ARMATURE	MS900PS.23	50	NAME PLATE 2	MS900PS.50
24	BEARING 608ZZ	MS900PS.24	501	PIN SPANNER	MS900PS.501
25	BEARING BUSHING	MS900PS.25	502	POLISHING DISK	MS900PS.502
26	GUIDE WIND CIRCLE	MS900PS.26	503	WOOLLEN FABRICS COVER	MS900PS.503