



Item	Part No.	Description
1	SFF16.01	Front Cap
2	SFF12.V2-02	Front Grille
3	SFF12.V2-03	Fan Blade
4	SFF12.V2-04	Screw
5	SFF12.V2-05	Motor
6	SFF12.V2-06	Screw
7	SFF12.V2-07	Cover
8	SFF12.V2-08	Screw
9	SFF12.V2-09	Capacitor
10	SFF12.V2-10	Cord Clip
12	SFF12.V2-12	Rear Grille
13	SFF12.V2-13	Screw

Item	Part No.	Description
14	SFF12.V2-14	Rotary Knob
15	SFF12.V2-15	Cover, Rotary Switch
16	SFF12.V2-16	Switch
17	SFF12.V2-17	Holder, Rotary Switch
18	SFF12.V2-18	Power Cord
19	SFF12.V2-19	Screw
20	SFF12.V2-20	Washer
21	SFF12.V2-21	Side, Switch Cover
22	SFF12.V2-22	Rubber Foot
23	SFF12.V2-23	Base
--	SFF12.V2-11	Screw (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.