



Item	Part No.	Description
1	VS8222.01	CLEAR LENS
2	VS8222.02	FRONT COVER
3	VS8222.03	LCD SCREEN
4	VS8222.04	LCD BACK PLATE
5	VS8222.05	SCREW
6	VS8222.06	PROBE SOCKET
7	VS8222.07	CONNECT PLATE
8	VS8222.08	ADJUSTMENT BUTTON
9	VS8222.09	MIDDLE SUPPORT
10	VS8222.10	SCREW

Item	Part No.	Description
11	VS8222.11	BATTERY CONNECTION
12	VS8222.12	BATTERY
13	VS8222.13	BATTERY PROTECTION
14	VS8222.14	BACK COVER
15	VS8222.15	SUPPORT BAR
--	VS8222.ACC1	PROBE 9mm (not shown)
--	VS8222.ACC2	45deg MIRROR (not shown)
--	VS8222.ACC3	MAGNETIC PICK-UP (not shown)
--	VS8222.ACC4	HOOK (not shown)
--	VS8222.SP	STORAGE POUCH (not shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.