



205LTR LIFT ACTION DRUM PUMP WITH MEASURE KIT

MODEL NO: **TP6808**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection



Wear protective gloves



Wear protective clothing



Wear safety footwear

1. SAFETY

- ✗ **DO NOT** use with any flammable liquids.
- ✗ **DO NOT** overfill the Safety Measure
- ✓ Wear appropriate protective clothing when pumping solvents. We recommend eye/face and hand protection, available from your authorised Sealey Stockist.
- ✓ Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this equipment.
- ✓ Ensure any spillages are dealt with immediately. Failure to do so could lead to injury.
- ✓ Keep children away from areas where solvents are being used.

2. INTRODUCTION

Made from high quality polypropylene and LDPE plastic, pump has a broad chemical resistance, including mild solvents. Acid resistant, caustic resistant, and resistant to chlorine based chemicals. Pumps soaps, cleaning chemicals, sanitisers, antifreeze, AdBlue®, battery acid and more. Supplied with adjustable 2" BSP adaptor and dip tube suitable for 205L drums. Features lift action operation which pumps on the way up as well as the down push, enabling a larger delivery per stroke. Supplied with a lock-on measuring bottle for effective pumping with no leaks or spillages. Pump also features a locking strap to prevent accidental operation whilst not in use.

3. ASSEMBLY

- 3.1. The pump can be held in place by the threaded insert. Screw the top of the insert down. You will feel the insert gripping the lifting tube.
- 3.2. The bottle connects to the filler by twisting.

4. OPERATION

- ✗ **DO NOT** use pump when spout is pointed upwards.
- 4.1. **RELEASING THE PUMP HANDLE.**
 - 4.1.1. Squeeze the sides of the retaining clip to force the locating bit out of the hole and slide the clip back off of the handle.

5. MAINTENANCE

- ✓ Store in a safe place away from children.
- ✓ Make sure the pump is empty before long term storage.

6. APPLICATION

For a full list of applications please see website for full application list.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.



fig.1

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk