

# Hinged Shower Door 800 x 1850mm, 6mm Tempered Glass, Reversible - Chrome/ Black



## Model No. DH306, DH307

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.


Important Information
Please read these instructions carefully and note any safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.

#### **Contents**

Please check all components shown in the component checklist. If any components are missing or damaged. Contact your point of purchase for replacement.

NO.	Description	QTY	Diagram
1	Wall profile	6	
2	Metric Screw(3.9x30)	14	()
3	Wall profile	2	
4	Screw cover cap	6	0
5	Screw cover cap	10	<b>1</b>
6	Wall profile	1	FH
7	Water retaining rubber strip	1	U
8	Glass	1	
9	Handle	1	OND.

NO		o.T./	
NO.	Description	QTY	Diagram
10	Water retaining rubber strip	1	LA
11	Pivot	2	#   
12	Pulley guide(Bottom)	1	
13	Metric Screw(3.9x10)	6	
14	Metric Screw(3.9x12)	4	
15	Pulley guide(top)	1	
16	Magnetic adhesive strip	1	
17	Wall profile	1	<b>\</b>



### **Specification**

- Colour of Product: DH306 Silver DH307 Glass/ Black
- · Glass Thickness: 6mm
- · Material: Aluminium Profile with Chrome/ Aluminium Profile with Chrome Finish
- · Nett Weight: 23kg
- Product Dimensions (W x D x H): 800 x 6 x 1850mm
- · Type: Hinge Shower Door


#### Safety


- HANDLE GLASS WITH CARE. Tempered glass is strong but can shatter if mishandled. Never set it directly on hard surfaces or strike the edges with tools.
- INSPECT BEFORE INSTALLATION. Check all parts for damage before starting. Damaged glass or components can pose serious risks.
- Use Proper Tools and Gear Always wear safety glasses when drilling or cutting. Use a spirit level, silicone gun, rubber mallet, and appropriate drill bits.
- AVOID RUSHING THE SEALANT. Allow silicone sealant to cure for at least 24–48 hours before using the shower to prevent leaks and ensure stability.
- TWO-PERSON JOB. Pivot doors are heavy and awkward to manoeuvre alone. Enlist help to avoid injury and ensure proper alignment.


#### **Mistakes to Avoid**


- · INCORRECT TRAY LEVELLING: If the shower tray isn't perfectly level, the door may not close properly or seal correctly.
- · SKIPPING WALL CHECKS Ensure walls are plumb and free of loose tiles or cracks. Uneven surfaces can compromise the door's function.
- · DO NOT apply silicone inside the enclosure. Only seal external joints to prevent mould and mildew build-up.
- To preserve surfaces and ensure safety, avoid harsh or abrasive cleaners. Opt instead for gentle soap and water, which clean effectively
  without damaging finishes.


### **Assembly**




















#### **Environment Protection and Waste Protection**

Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of it's useful life, please dispose of it in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.