



INSTRUCTION MANUAL FOR: AIR OPERATED NAIL GUN MODEL No: SA791

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

- WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this equipment.
- WARNING!** Disconnect from air supply before refilling, servicing or performing maintenance.
- ✓ Maintain the nail gun in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. Use genuine parts only. Non-authorized parts may be dangerous and will invalidate the warranty.
- ✓ Use in suitable clean and tidy work area, free from unrelated materials and ensure there is adequate lighting.
- WARNING!** Always wear approved eye and/or face and hand protection when operating the nail gun.
- ✓ Remove ill fitting clothing. Remove ties, loose jewellery, and contain and/or tie back long hair.
- ✓ Wear appropriate protective clothing and keep hands and body clear of working parts.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Keep children and unauthorised persons away from the working area.
- ✓ Check moving parts alignment on a regular basis.
- ✓ Ensure workpiece is secure before operating the nail gun. Never hold a workpiece by hand.
- ✓ When the nail gun is put down during pauses in operation ensure that the trigger catch slide is not depressed by the weight of the nail gun or by placing the nail gun in a restricted position that could put pressure on the trigger catch slide.
- ✓ During extended breaks in operation disconnect the nail gun from the air supply.
- WARNING!** Ensure correct air pressure is maintained and not exceeded. Recommended pressure 60-100psi.
- ✓ Keep air hose away from heat, oil and sharp edges. Check air hose for wear before each use and ensure that all connections are secure.
- ✓ Prolonged exposure to vibration from this nail gun may pose a health risk. It is the owner's responsibility to correctly assess the potential hazard and issue guidelines for safe periods of use and offer suitable protective equipment.
- ✗ **DO NOT** point the nail discharge outlet at yourself or anyone else. Do not point at animals.
- ✗ **DO NOT** use any power source except an air compressor.
- ✗ **DO NOT** operate the nail gun near any flammable substance or on any container that once contained a flammable substance.
- ✗ **DO NOT** use the nail gun for a task it is not designed to perform.
- ✗ **DO NOT** operate nail gun if any parts are damaged or missing as this may cause failure and/or personal injury.
- ✗ **DO NOT** carry the nail gun by the hose, or yank the hose from the air supply.
- ✗ **DO NOT** place the nail gun close to your face and do not point at other persons or animals.
- ✗ **DO NOT** operate nail gun when you are tired, under the influence of alcohol, drugs or intoxicating medication.
- ✗ **DO NOT** carry the nail gun with your finger on the trigger.
- ✗ **DO NOT** direct air from the air hose at yourself or others.
- ✓ When not in use, disconnect from the air supply and store in a safe, dry, childproof location.

2. INTRODUCTION

Professional air nailer with lightweight aluminium body and rubber grip handle. Safety trigger device to prevent accidental firing of nails. Incorporates quick jam release mechanism. Supplied in carry-case with oiler and starter pack of nails.

3. SPECIFICATION

Model: SA791	Air inlet: 1/4" BSP	Noise Pressure: 88.2dB
Nail Capacity: 15-50mm 18SWG	Weight: 1.4kg	Vibration: 1.5m/s ²
Maximum pressure: 120psi	Noise Power: 93.3dB	Uncertainty: 0.75m/s ²

4. PREPARATION

4.1. Air Supply

- 4.1.1. Before connecting to an air supply ensure that the trigger catch release slide is not depressed (see fig.3).
- 4.1.2. You will require an air pressure between 60-120psi.
- 4.1.3. **WARNING!** Ensure the air supply is clean and does not exceed 120psi while operating the nail gun.
Too high an air pressure and unclean air will shorten the product life due to excessive wear and may be dangerous, causing damage and/or personal injury.
- 4.1.4. Drain the air tank daily. Water in the air line will damage the nail gun **and will invalidate your warranty.**
- 4.1.5. Clean air inlet filter weekly. Recommended hook-up procedure is shown in fig.1.
- 4.1.6. Line pressure should be increased to compensate for unusually long air hoses (over 8 metres).
The minimum hose diameter should be 1/4" I.D. and fittings must have the same bore.
- 4.1.7. Keep hose away from heat, oil and sharp edges. Check hoses for wear, and make certain that all connections are secure.

4.2. Couplings.

Vibration may cause failure if a quick change coupling is connected directly to the air nail gun. To overcome this, connect a leader hose to the nail gun. A quick change coupling may then be used to connect the leader hose to the air line recoil hose (see figs 1 & 2).




fig.2





fig.1

fig.3

5. OPERATION

WARNING! Ensure you read, understand and apply safety instructions before use.

- 5.1. Load the magazine before connecting the airline. To open the magazine, hold the nail gun vertically with one hand, then with the thumb of your other hand, press the magazine catch upwards and slide the magazine backwards and open with the forefinger of the same hand. Place a stick of nails into the open magazine chamber ensuring that all nails have their points resting on the bottom of the chamber.
- 5.2. Slide the magazine cover shut until it clicks into place behind the catch.
- 5.3. Before connecting to an air supply, ensure that the trigger catch release slide is NOT depressed. Connect the air line to the nail gun as described in Section 4.
- 5.4. The operating trigger is normally locked and cannot be used until the trigger release slide is depressed. This happens automatically as you position the nail gun.
- 5.5. The trigger release slide can be seen protruding downwards just in front of the nail outlet (see fig.1). Place the tip of the slide onto the material to be nailed and press downwards to bring the nail outlet into contact with the surface. As the slide retracts the trigger will become free.
- 5.6. Depress the trigger to fire one nail. To fire another nail, release the trigger, reposition the nail gun at the next required nailing point and depress the trigger again. Repeat as necessary.
- 5.7. If you need to put the nail gun down during the course of working ensure that the trigger slide catch is not depressed against any object.
- 5.8. When the work is complete or when you have paused for any length of time, disconnect the nail gun from the air line.
- WARNING! Should a blockage occur, disconnect nail gun from the air supply immediately.**
- 5.9. Open the magazine as described above.
- 5.10. Access the blockage by unclipping the driver guide front-plate (see fig 1) using the release catch provided.
- 5.11. Remove the nail and any foreign matter found within the driver guide.
- 5.12. Replace the driver guide front-plate and set the catch.
- 5.13. Ensure that all parts of the nail gun are secure and correctly positioned, then reconnect the air supply.

6. MAINTENANCE

- WARNING! Disconnect nail gun from air supply before refilling with nails, servicing or performing maintenance. Replace or repair damaged parts. Use genuine parts only. Non-authorized parts may be dangerous and will invalidate the warranty.**
- 6.1. Lubricate the air nail gun daily with a few drops of the air tool oil supplied, dripped into the air inlet before use. To re-order air tool oil use Sealey part No's. ATO500S or ATO1000S.
 - 6.2. Clean the nail gun after use.
 - 6.3. Loss of power or erratic action may be due to the following:
 - a) Excessive drain on the air line. Moisture or restriction in the air pipe. Incorrect size or type of hose connectors. To remedy check the air supply and follow instructions in section 4.
 - b) Grit or gum deposits in the nail gun may also reduce performance. Flush the nail gun out with gum solvent oil or an equal mixture of SAE No.10 oil and kerosene. Allow to dry before use.
If you continue to experience problems, contact your local Sealey service agent.
 - 6.4. For a full service contact your local Sealey service agent.
 - 6.5. When not in use, disconnect from air supply, clean nail gun and store in a safe, dry, childproof location.
 - 6.6. On a weekly basis check the security of the hex bolts holding the driver guide plate in place and tighten if necessary (fig.1).



Environmental Protection

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain off any fluids (if applicable) into approved containers and dispose of the product and the fluids according to local regulations.

Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or telephone 01284 757500.

WARNING! – Risk of Hand Arm Vibration Injury.

This tool may cause Hand Arm Vibration Syndrome if its use is not managed adequately.

This tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC.
This tool is to be operated in accordance with these instructions.

Measured vibration emission value (a): 1.5m/s²

Uncertainty value (k): 0.75m/s²

Please note that the application of the tool to a sole specialist task may produce a different average vibration emission. We recommend that a specific evaluation of the vibration emission is conducted prior to commencing with a specialist task.

A health and safety assessment by the user (or employer) will need to be carried out to determine the suitable duration of use for each tool.

NB: Stated Vibration Emission values are type-test values and are intended to be typical.

Whilst in use, the actual value will vary considerably from and depend on many factors.

Such factors include; the operator, the task and the inserted tool or consumable.

NB: ensure that the length of leader hoses is sufficient to allow unrestricted use, as this also helps to reduce vibration.

The state of maintenance of the tool itself is also an important factor, a poorly maintained tool will also increase the risk of Hand Arm Vibration Syndrome.

Health surveillance.

We recommend a programme of health surveillance to detect early symptoms of vibration injury so that management procedures can be modified accordingly.

Personal protective equipment.

We are not aware of any personal protective equipment (PPE) that provides protection against vibration injury that may result from the uncontrolled use of this tool. We recommend a sufficient supply of clothing (including gloves) to enable the operator to remain warm and dry and maintain good blood circulation in fingers etc. Please note that the most effective protection is prevention, please refer to the Correct Use and Maintenance section in these instructions. Guidance relating to the management of hand arm vibration can be found on the HSC website www.hse.gov.uk - Hand-Arm Vibration at Work.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR



01284 757500



01284 703534



www.sealey.co.uk



sales@sealey.co.uk