



DIGITAL THERMOMETER, TEMPERATURE PROBE, AUTO-POWER-OFF, LCD SCREEN


MODEL NO: **VS1000.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



1. SAFETY

- WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this equipment.
- Familiarise yourself with the application and limitations of the product, as well as potential hazards peculiar to the use of the thermometer.
- Keep the thermometer clean for best and safest performance.
- Store the thermometer with the protective cover in place over the probe when not in use.
- When not in use, store in a safe, dry, childproof area.
- DO NOT** use equipment for any purpose other than that for which it is designed.
- DO NOT** allow untrained persons to operate the thermometer.
- DO NOT** use the thermometer to test objects above 270°C.

2. INTRODUCTION

High precision digital stainless steel temperature probe. Large LCD digital screen for clear and accurate readings. Measurements displayed in both °C and °F. Measurement range -50°C to 270°C (-58°F to 518°F). Auto-power-off after 8mins. Powered by 2 x LR44 batteries (supplied) with low power indication. Ideal for testing automotive air conditioning output.

3. FEATURES



4. SPECIFICATION

Model No:..... **VS1000**
Accuracy: ±1.5%
Temperature Range:-50°C~ -20°C(±1.5%); -20°C~200°C(±1%); 200°C~270°C(±2.0%)

5. OPERATION

- 5.1. Fit batteries: slide off cover on back, observe polarity indicated, refit cover.
- 5.1.1. When the battery level drops to a low level and needs replacing, the screen will display:
- 5.2. Remove the protective cover from the probe.
- 5.3. Turn **ON**: press the **ON/OFF HOLD** button. The display will show all its symbols momentarily and then revert to displaying current temperature reading.
- 5.4. Position the probe tip in the required location and once the tip of the probe has sensed the temperature, the display will change to display the measured temperature.
- 5.5. **HOLD FUNCTION**: press the **ON/OFF HOLD** button again.
- 5.6. To switch the temperature display between Centigrade and Fahrenheit, press the **°C/°F** button.
- 5.7. **TURN OFF**: Long press **ON/OFF HOLD** button.
- NOTE:** Current readings are not held in memory when the thermometer is turned off.
- 5.8. If the thermometer is on but not in use, it will turn itself off after approximately 8 minutes.

6. MAINTENANCE

- 6.1. After use, clean the probe and body with cloth dampened in warm water and replace the protective cover.
- 6.2. This item does not have any serviceable parts. **DO NOT** dismantle or attempt to modify the unit. This will invalidate the warranty.

7. BATTERY SAFETY

SYMPTOMS ARISING FROM BATTERY INGESTION

No obvious symptoms

Unfortunately it is not obvious when a button or coin battery is stuck in a child's oesophagus (food pipe).

There are no specific symptoms associated with this. The child might:

- cough, gag or drool a lot.
- appear to have a stomach upset or a virus.
- be sick.
- point to their throat or stomach.
- have pain in their abdomen, chest or throat.
- be tired or lethargic.
- be quieter or more clingy than usual or otherwise 'not themselves'.
- lose their appetite or have reduced appetite; and
- not want to eat solid food / be unable to eat solid food.

These sorts of symptoms vary or fluctuate, with pain increasing and then subsiding.

A specific symptom to button and coin battery ingestion is vomiting fresh (bright red) blood. If the child does this seek immediate medical help.

8. END OF LIFE

- 8.1. Remove batteries. Dispose of batteries and body according to Regulations in force.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk